


Door Components

Bronco 1966-77



SS = Stainless Steel

PART	ILL#	DESCRIPTION AND APPLICATION	REQD	LIST	SELL
49-9340	(1)	DOOR WEATHERSTRIP SET-UPPER BRONCO	66-77 (1)	37.44	29.95
49-9344	(2)	DOOR WEATHERSTRIP SET-LOWER BRONCO	66-77 (1)	62.44	49.95
40-2670	(3)	DOOR LOCK KNOB SET-CHROME BRONCO	66-67 (1)	6.19	4.95
40-2671		DOOR LOCK KNOB SET-CHROME BRONCO	68-77 (1)	7.44	5.95
40-2680	(4)	DOOR LOCK KNOB SET-BLACK BRONCO	66-77 (1)	6.19	4.95
49-7616	(5)	DOOR HANDLE-INSIDE BRONCO	66 (2)	21.19	16.95
49-7620	(6)	DOOR HANDLE-INSIDE BRONCO	67 (2)	12.44	9.95
40-2609	(7)	ESCUTCHEON BRONCO	67 (2)	2.44	1.95
49-7224	(8)	DOOR HANDLE RELEASE-LH BRONCO	66-67 (1)	24.94	19.95
49-7225		DOOR HANDLE RELEASE-RH BRONCO	66-67 (1)	24.94	19.95
49-7622	(9)	DOOR HANDLE-INSIDE-LH BRONCO	68-77 (1)	18.69	14.95
49-7623		DOOR HANDLE-INSIDE-RH BRONCO	68-77 (1)	18.69	14.95
40-0943	(10)	NUT W/WASHER-HANDLE BRONCO	68-77 (4)	.44	.35
49-5409	(11)	DOOR HANDLE CUP-BLACK "A" BRONCO	68-77 (2)	9.94	7.95
49-7244	(12)	DOOR HANDLE RELEASE-LH BRONCO	68-77 (1)	31.19	24.95
49-7245		DOOR HANDLE RELEASE-RH BRONCO	68-77 (1)	31.19	24.95
40-0460	(13)	SCREW-HANDLE RELEASE BRONCO	68-77 (2)	2.44	1.95
49-7236	(14)	DOOR LATCH-LH BRONCO	66-67 (1)	112.44	89.95
49-7237		DOOR LATCH-RH BRONCO	66-67 (1)	112.44	89.95
49-7266		DOOR LATCH-LH BRONCO	68-77 (1)	124.94	99.95
49-7267		DOOR LATCH-RH BRONCO	68-77 (1)	124.94	99.95
40-0460	(15)	SCREW-DOOR LATCH BRONCO	68-77 (6)	2.44	1.95
40-1362	(16)	DOOR LATCH ROD RETAINER BRONCO	66-77(12)	1.56	1.25


Note: "A" Paint to match interior color.
 "B" Includes polished stainless steel mounting hardware.
 "C" Reverse pin for right hand application.

PART	ILL#	DESCRIPTION AND APPLICATION	REQD	LIST	SELL
40-0447	(17)	SCREW-ARMREST BRONCO	66-77 A/R	.50	.40
40-0800	(18)	RETAINER-ARMREST SCREW BRONCO	66-77 A/R	1.81	1.45
40-0441	(19)	SCREW-DOOR PANEL-SS BRONCO	66-77(20)	.81	.65
40-0445		SCREW-DOOR PANEL-BLACK BRONCO	66-77(20)	.56	.45
40-0799	(20)	J-NUT-DOOR PANEL SCREW BRONCO	66-77(20)	.81	.65
49-7618	(21)	DOOR HANDLE ASSY-OUTSIDE-LH BRONCO	66-77 (1)	24.94	19.95
49-7619		DOOR HANDLE ASSY-OUTSIDE-RH BRONCO	66-77 (1)	24.94	19.95
49-7608	(22)	PAD SET-HANDLE 4PC BRONCO	66-77 (1)	6.19	4.95
47-0693	(23)	DOOR/IGN LOCK SET-MATCHED BRONCO	66-67 (1)	49.94	39.95
47-0701		DOOR/IGN LOCK SET-MATCHED BRONCO	68-77 (1)	74.94	59.95
47-0595	(24)	DOOR LOCK CYLINDER GASKET BRONCO	66-67 (2)	2.44	1.95
49-7799	(25)	STRIKER PLATE & SHIM SET BRONCO	66-67 (2)	18.69	14.95
49-7801		STRIKER PLATE & SHIM SET BRONCO	68-77 (2)	21.19	16.95
40-0449	(26)	SCREW-STRIKER PLATE BRONCO	66-77 (4)	1.19	.95
40-2799	(27)	HINGE REPAIR KIT BRONCO	66-77 (1)	49.94	39.95
49-7849	(28)	DOOR CHECK STRAP SET "B" BRONCO	66-77 (1)	24.94	19.95
40-0518	(29)	SCREW-SS BRONCO	66-77 (8)	.81	.65
49-7850	(30)	CHECK STRAP-REPLACEMENT BRONCO	66-77 (2)	4.94	3.95
49-7265	(31)	DOOR HINGE "C" BRONCO	66-77 (4)	43.69	34.95
40-2780	(32)	DOOR HINGE PIN W/GROOVES BRONCO	66-77 (4)	3.69	2.95
40-0278	(33)	DOOR HINGE BOLT BRONCO	66-77(24)	.56	.45
40-0623	(34)	LOCK WASHER BRONCO	66-77(24)	.44	.35

Door Glass and Components

Bronco 1966-77

Loctite Viper Lube
See Page 36



Door Panel Sets
See Page 50

PART	ILL#	DESCRIPTION AND APPLICATION	REQD	LIST	SELL
49-7345	(1)	DOOR GLASS-CLEAR	BRONCO 66-77 (2)	62.44	49.95
49-7346		DOOR GLASS-TINTED	BRONCO 66-77 (2)	62.44	49.95
49-7146	(2)	ANTI-RATTLE KIT-DOOR 12PC	BRONCO 66-77 (1)	312.44	249.95
49-7120	(3)	UPPER GLASS CHANNEL SET 2PC	BRONCO 66-77 (1)	49.94	39.95
49-7126	(4)	LWR DIVISION BAR SET-LOCK	BRONCO 66-77 (1)	87.44	69.95
49-7122	(5)	UPPER VERTICAL DIVISION BAR	BRONCO 66-77 (2)	24.94	19.95
49-7124	(6)	LWR DIVISION BAR SET-HINGE	BRONCO 66-77 (1)	87.44	69.95
49-7116	(7)	ANTI-RATTLE KIT-WINDOW 2PC	BRONCO 66-77 (2)	31.19	24.95

49-9300	(8)	CHANNEL RUBBER	BRONCO 66-77 (2)	16.19	12.95
49-7218	(9)	WINDOW LIFT CHANNEL	BRONCO 66-77 (2)	31.19	24.95
49-7918	(10)	WINDOW REGULATOR-LH	BRONCO 67-77 (1)	124.94	99.95
49-7919		WINDOW REGULATOR-RH	BRONCO 67-77 (1)	124.94	99.95
49-7862	(11)	REGULATOR ROLLER ASSEMBLY	BRONCO 66-77 (2)	4.94	3.95
41-1575	(12)	DOOR GLASS BUMPER SET	BRONCO 66-77 (1)	3.69	2.95
49-7636	(13)	WINDOW HANDLE W/KNOB	BRONCO 66 (2)	16.19	12.95
49-7640	(14)	WINDOW HANDLE W/KNOB	BRONCO 67 (2)	16.19	12.95
40-2609	(15)	ESCUTCHEON	BRONCO 67 (2)	2.44	1.95
49-7642	(16)	WINDOW HANDLE W/O KNOB	BRONCO 68-77 (2)	12.44	9.95
49-7643	(17)	HANDLE SCREW COVER	BRONCO 68-77 (2)	1.19	.95
40-2608	(18)	ESCUTCHEON	BRONCO 68-77 (2)	2.44	1.95
40-2620-BL	(19)	KNOB-HANDLE-BLACK	BRONCO 68-77 (2)	6.19	4.95
40-2620-CL		KNOB-HANDLE-CLEAR	BRONCO 68-77 (2)	6.19	4.95
40-2620-WH		KNOB-HANDLE-WHITE	BRONCO 68-77 (2)	6.19	4.95

Power Window Kit

Double switch construction allows the driver to operate both windows. The components are concealed inside the door to give you added security. Comes with easy-to-follow instructions, hardware and color coded wiring harness for error-free installation.




47-1105

PART	DESCRIPTION AND APPLICATION	REQD	LIST	SELL
47-1105	POWER WINDOW KIT	BRONCO 66-77 (1)	212.44	169.95

Vent Window Lock Prevents Costly Break-ins

Help prevent costly break-ins with this universal Vent Window Lock Set. Made from heavy-gauge steel, the locks install easily without tools and are removable when not in use. Add to the security of your investment; call or go online and order yours today!



49-7691

49-7691	VENT WINDOW LOCK	SET OF 2	(1)	12.44	9.95
---------	------------------	----------	-----	-------	------